

Alcolizer HH2

Portable Dual Mode

Breath Alcohol Tester

Introduction

The Alcolizer HH2 portable breath alcohol tester is simple to use and gives accurate and reliable results at a reasonable price. It has a variety of applications and is ideal for the budget conscious buyer, and is certified to Australian Standards AS 3547 – 1997.

Reliable Accuracy

The Alcolizer HH2 is designed and manufactured by Alcolizer Technology (AT), an Australian firm with a high reputation in the manufacture of quality breath testers.

The Alcolizer HH2 uses the same advanced sensor technology used for years in police breath testers worldwide, combined with the latest in microprocessor technology.

Easy to Live With

Alcolizer HH2 is small and uses a 9 volt alkaline battery so that it can be used anywhere. Mouthpieces are supplied, and additional mouthpieces are available. AT provides a recalibration service – and the HH2 even tells you when it is due!

Easy Operation

Simply switch on the Alcolizer HH2 and observe the automatic circuit testing. The display shows when the unit is ready. For active testing, just breathe into the mouthpiece for a few seconds until the audio tone signals that the test is complete. The blood alcohol content is indicated on the meter to the nearest 0.001% for each test. The unit powers down after testing to save battery power.

Data Logging

Stores up to 1000 tests, recording gender, date, time, BAC reading

Optional Equipment

Options include small impact printers, thermal printers, kit form, leather cases and holders. Various types of mouthpieces are available

The Bottom Line

The Alcolizer HH2 is an economic solution for many breath-testing applications and is widely used in Australia by industry and individuals. It is flexible enough for any application.





ALCOLIZER HH2 - SPECIFICATIONS

Size:	14.5 cm x 6.8 cm x 2.5 cm
Weight:	200 grams
Accuracy:	Better than 10% (0.010 at 0.10% BAC)
Number of tests:	up to 1000 tests with fresh batteries or 12 months
Batteries:	9v alkaline
Operation in ambient temperature:	0°C to +40°C (30°F to 100°F)
Purge cycle:	30 seconds
Breath sample:	5-second moderate and continuous breath sample
Readout	Immediate
Automatic power down:	After 30 seconds of inactivity the unit shuts off
Smoking caution:	Wait 3 minutes
Drinking (alcohol consumption) caution:	Wait 15 minutes
Mouthpieces	Round type with sputum trap/ straight through
Calibration:	Mail-in calibration service by AT technicians
Display:	LCD with backlight
Display Format:	BAC
Complete package includes:	Vinyl case, serial cable and CD 4 mouthpieces Operating Manual

Warranty

Alcolizer HH2 personal alcohol testers are warranted to be free from defects in workmanship and material for one year from the date of shipment by AT Pty Ltd. AT Pty Ltd will replace or repair any unit or part that in its judgment is found to be defective, providing that the defect has not been caused by misuse or mishandling. Units in warranty must be properly packaged and shipped prepaid to AT Pty Ltd.